LED LAMP

SV Series



LED Wi-Fi A19 Bulb **SV-A19**







2-year limited warranty

Operating temperature range -40 $^{\circ}$ C $^{\sim}$ +45 $^{\circ}$ C











Features & Benefits

Smart Control	Use TuroSmart app to control your light from anywhere you have internet access.
Easy Dimming	No need to install a dimmer, our WiFi A19 LED easily dims to the desired light level.
Tunable White	Independent from dimming, choose your white from 2700K to 5000K.
Color Change	Tap on any light color from our full spectrum wheel to match your specific mood.
Set a Schedule	Have your lights come on or off when you want.
Use Your Voice	Activate using Amazon Alexa or Google Assistant.

Dimensional Drawing



Product Specification

Ordering Code	Model Number	Wattage	Replacement Incandescent	Base	Voltage (V)	Hour Rating	Beam	Lumens (lm)	CCT(K)	CRI	Damp	M.O.L. (inch)	Case OTY.
coue	Model Nulliber	(VV)	ilicaliuescelli	Dase	(V)	natiliy	Angle	(1111)	CCT(R)	CNI	Location	(IIICII)	QII.
1962000	SV-A19/10W/WIFI/D	10	60W	E26	120	15,000	220°	800	2700-5000	80	Υ	4.3	50

Using Guide

- 1. Download APP "TuroSmart" in "Apple Store" or "Google Play".
- 2. Install WiFi LED bulb in the fixture/socket.
- 3. Switch on and off the bulb repeatedly until the bulb blinks, normally after 3 or 4 times. After the bulb blinks, it will enter the networking connection mode just in a few seconds
- 4. Make your phone wifi connected, then open the APP "TuroSmart" and follow "Setup Guide" to set your smart lamp.



Bulb Setup Guide











